

Snapshot and Recorder Installation & Navigation Guide

macOS

OKIOCAM Snapshot and Recorder is OKIOCAM's principal application. This guide will walk you through how to install it on macOS.

Step 1


In a web browser, go to the OKIOLABS download page (www.okiolabs.com/download/).

Step 2

Click on **OKIOCAM Snapshot and Recorder** to start the download.

Step 3

After the download has completed, click on the **Downloads** folder.




**Step
4**

Click on **OKIOCAM Snapshot and Recorder** to start the installation.


**Step
5**

Click on **OKIOCAM Snapshot and Recorder** and drag and drop it to **Applications**.




**Step
6**

Double click on **Applications**. The Applications folder will open.


**Step
7**

Locate OKIOCAM Snapshot and Recorder in the Applications folder. Right click on **OKIOCAM Snapshot and Recorder** and click on **Open**.




**Step
8**

A dialog box will pop up asking you to confirm that you wish to open OKIOCAM Snapshot and Recorder. Click **Open**.


**Step
9**

After Snapshot and Recorder has opened, a dialog box will appear asking you to confirm that you want to allow OKIOCAM Snapshot and Recorder access to your camera. Click **OK**.



**Step
10**


Click the **OKIOCAM Snapshot and Recorder icon** on the Dock to launch OKIOCAM Snapshot and Recorder in the future.













If you have Mac OS X 10.6.6 or later, you can also install OKIOCAM Snapshot and Recorder via the Mac App Store.

Features & Navigation

Live
View




- 1 Press  to show the **Menu**. Press again to hide.
- 2 Press  to turn on **Selfie Mode**. Press again to turn off. Selfie Mode flips the camera 180°.
- 3 Press  to access the **Settings** menu.
- 4 Press  to toggle in and out of **Fullscreen**. You can also press Esc to exit **Fullscreen**.
- 5 Press  to access the **Settings** menu.
- 6 Press  to take a snapshot.
- 7 Press  to start recording video. Press  to pause the recording. Press  to stop the recording.
- 8 Press  to enter **Review Mode**.


Menu



Use the **Zoom** control to adjust the level of zoom. Press the and icons to adjust the level of zoom in increments of .1x, between 1x and 6x. Zoom can also be adjusted using the slider by left-clicking on and dragging the mouse either up or down.



Use the **Rotate** control to rotate the camera display clockwise and counterclockwise in increments of 90°. rotates the camera display clockwise and rotates counterclockwise.



Use the **Exposure** control to adjust the level of exposure. Press the and icons to adjust the level of exposure in increments of 1, between -7 and +7. Exposure can also be adjusted using the slider by left-clicking on and dragging the mouse either up or down.



Press the **Freeze** button to freeze the camera feed.




Press the **Focus / Auto adjust** button to adjust the camera's focus, exposure, and white balance automatically.




Press the **Reset** button to reset the camera.

Settings




General Setting	
Camera	OKIOCAM S (eb1a:8021) ▼
Resolution	1920x1080 ▼
Focus Sound	Off ▼
Library Folder	/Users/THChan/OKIOCAM Files/ Change



800x600
1024x768
1280x720
1600x1200
1920x1080
1920x1440
2048x1536
2592x1458
2592x1944




The resolutions
available when using
OKIOCAM T



800x600
1024x768
1280x720
1600x1200
1920x1080
1920x1440




The resolutions
available when using
OKIOCAM S


- From the **Camera** drop-down menu, you can choose which camera you want to use with OKIOCAM Snapshot and Recorder.
- Use the **Resolution** drop-down menu to select which resolution you would like to view the Live View and take your snapshots in. Available resolutions will depend on which camera you are using.
- Use the **Focus Sound** drop-down menu to select whether you want to hear a sound after the camera has finished focusing.
- Change the **Library Folder** by clicking on the Change icon. The Library Folder is the directory that your OKIOCAM Snapshot and Recorder files are stored in on your computer.

Record Setting	
Ratio	4:3 ▼
Quality	Low (1024x768 or 1280x720) ▼
Recording Mic	None ▼
Mic Volume	
 Display when recording 	
Note: Maximum recording length is 60 minutes.	

Low (1024x768 or 1280x720)
High (1600x1200 or 1920x1080)


The resolutions available
when using both
OKIOCAM S and OKIOCAM T

- Use the **Ratio** drop-down menu to choose the aspect ratio that videos are recorded in (choose from either 4:3 or 16:9).
- Select the quality that videos are recorded in. Choose from either **Low** or **High**. Recorded video resolution will depend on which aspect ratio you have selected.
- If you want to record audio, choose which microphone you want to record from using the **Recording Mic** drop-down menu. If you do not want to record audio, select **None**.
- Set the microphone volume using the slider in the **Mic Volume** section. Drag the  icon towards the right to raise the recording volume and towards the left to lower the recording volume. Set the **Display when recording** setting to the on position () if you want to have the ability to adjust the microphone volume directly from within the Live View when recording, and set it to the off position () if you do not.




- Use the drop-down menus to reassign different functions to the physical buttons on the camera.

- Choose the zoom ratios that will be cycled through when the button assigned to the zoom function is pressed. Input custom zoom ratios if you wish.




- Assign a shutter timer time of either 0, 2, or 5 seconds using the **Shutter Timer** drop-down menu. The shutter timer triggers every time you take a snapshot.


- If **Post-Shot Review** is set to **Yes**, after you take a snapshot you will be taken directly to **Review Mode**. If it is set to **No**, you will not be.



Press **Quit** to exit OKIOLAB Snapshot and Recorder.









Press **About Us** to learn more about available OKIOLAB apps.



Press **Help** to open the OKIOLABS support website.

Review Mode



- 1 Press  to go back to the Live View.
- 2 Press  to open your Library Folder.
- 3 Press  to delete any selected files from your computer and Google Drive.
- 4 Press  to be presented with the option to delete all files, open a selected file in a new tab, or view information (File Name, Resolution, Create Date, File Size) for a selected file.
- 5 Press  to toggle in and out of **Fullscreen**.
- 6 Left-click on a file to select it. Right-click on a selected file to be presented with the option to delete the file.

Thank you!

**For more information, visit
<https://okiolabs.com/>**

**Need help? Contact us at
support@okiolabs.com**

**Sales inquiries? Contact us at
sales@okiolabs.com**